

# TERAFLEX

INSTALLATION GUIDE

## Installation Guide for the TeraFlex JK Wrangler CB Antenna Mount

Part #004997100 (Skin Packed)

Part #004997190 (Boxed)



Kit Includes:

- 1- CB antenna bracket
- 2- 8mm x 40 bolts
- 2- 8mm flat washers
- 2- 8mm split lock washers

**NOTE:** This CB mount has 2 holes for installing your CB antenna of choice. Either hole will work.

**WARNING:** Neither the seller nor the manufacturer will be liable for any loss, damage, or injury directly or indirectly arising from the use of or inability to determine the use of these products. Before using, the user shall determine the suitability of the products for its intended use, and the user shall assume all responsibility and risk in connection therewith.



1. Remove the spare tire
2. Remove the 2 factory bolts from the upper right hand side of the factory spare tire mount
3. Install the CB antenna mount as shown in the photo using the 2 new 8mm x 40 bolts with split lock washers and flat washers
4. Tighten the new bolts to not more than 10 ft. lbs. of torque
5. Install your antenna of choice following the manufacturer's installation instructions. Carefully route the antenna cable through the grommet in the tailgate. Remove the plastic cover on the inside of the tailgate and route the antenna cable along side the brake light wires. Reinstall the cover
6. Reinstall the spare tire on the tire carrier